

nickelodeon

TEENAGE MUTANT NINJA TURTLES

To change batteries:

- Take out old batteries and replace with 2 new AAA batteries.
- Replace battery covers.

Battery Instructions:


- Non-rechargeable batteries are not to be recharged.
- Different types of batteries or new and used batteries are not to be mixed.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Batteries are to be removed from the toys when not in use.
- Batteries should only be replaced by an adult.
- Do not dispose of batteries in fire.
- Do not use rechargeable batteries.

Batteries Regulation:

Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Under an environment with severe electrostatic discharge, the product may malfunction and require user reset.



TURTLE TALKIN' LEONARDO


To reset:

Unscrew battery cover, remove batteries and install again.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.



To Play:

Press button on belt

to activate sounds.

Sounds are randomized.

Age 4 and up
Asst. #91196
Item #91287

Playmates
TOYS

©2016 Viacom International Inc. All Rights Reserved.
Nickelodeon, TEENAGE MUTANT NINJA TURTLES
and all related titles, logos and characters
are trademarks of Viacom International Inc.

©2016 Playmates, Playmates International Company Ltd.
23/F, The Toy House, 100 Canton Road,
TST, Kowloon, Hong Kong. PRINTED IN CHINA.