


nickelodeon™
TEENAGE MUTANT NINJA
TURTLES™


HOVER DRONE
TRI-TURBO ROTO-RAIDER

Place figure on the Hover Drone by placing the figure's foot onto the foot peg on the platform. Then place the figure's hand around the steering column handles.


Insert missiles as shown.





Important:
 Do not fire at people, animals or at eyes or faces. Do not use projectiles other than those provided with this toy.



Fire the missiles by pressing the button on the side of the launcher as shown.



Attach steering column as shown to assemble the Hover Drone. Attach labels 1-5 as shown.



Push Hover Drone forward or backward on a smooth surface to make the triple turbines spin.

For more detailed instruction information visit www.Playmatestoys.com
 Figure sold separately

Ages 4 and up
 Asst. #94050
 Item #94055



©2013 Viacom International Inc. All Rights Reserved. TEENAGE MUTANT NINJA TURTLES and all related titles, logos and characters are trademarks of Viacom International Inc.
 ©2013 Viacom Overseas Holdings C.V. All Rights Reserved.
 TEENAGE MUTANT NINJA TURTLES and all related titles, logos and characters are trademarks of Viacom Overseas Holdings C.V.
 © 2013 Playmates Toys Inc. Distributed by Playmates Toys Inc. 909 N. Sepulveda Blvd., Suite 800, El Segundo, CA 90245.
 PRINTED IN CHINA.